

A few hand movements and your metal tube is folded and coded





Simple folding and coding appliance



With some hand movements you close your metal tubes with a double fold and subsequently you emboss the tube fold with a production code. This appliance is suitable for laboratories in pharmaceutical companies or the food industry as well as for small scale production in drug stores or pharmacies.

WORKING METHOD OF GRISOTUB M

The operation of this appliance is very easy:

At first you insert the filled tube vertically and by pulling of the hand lever the tube end will be squeezed; afterwards you insert the tube horizontally and bend it over to get a fold; this procedure has to be repeated so you receive a double fold; finally you insert the tube in the coding slot for embossing.

	TECHNICAL DATA	
Dimensions	 width 	120mm
	 depth 	200mm
	 height 	330mm
Weight	 approx. 	3.6kg
Tube dimensions	 length 	30 – 250mm
	• Ø	10 – 50mm
Output	 300 until 600 tubes per hour – depends on operator 	
Accessories	 coding set for embossing of an expiration date or a production lot number 	